



Bit Socket | T-Star for VAG polyDrive cylinder head bolts

CV		12.5mm $\frac{1}{2}$"	168 mm
	polyDrive	T52	9386












Quick-Finder

Impact Bit Sockets

Quick-Finder

Impact Bit Sockets

			12.5mm $\frac{1}{2}$"			20mm $\frac{3}{4}$"	CV	CRO MO	
		42 mm	55 mm	75 mm	100 mm	140 mm			
	T20	5486-T20	5369	5480-T20	5469				
	T25	5486-T25	5370	5480-T25	5470				
	T27	5486-T27	5367		5467				
	T30	5486-T30	5371	5480-T30					
	T40	5486-T40	5372	5480-T40					
	T45	5486-T45	5373	5480-T45				5545	
	T47		5378						
	T50	5486-T50	5374	5480-T50	5474			5550	
	T55	5486-T55	5375	5480-T55	5475			5555	
	T60	5486-T60		5480-T60				5560	
	T65							5565	
T70	5486-T70			5480-T70			5570		
T80	5486-T80			5480-T80			5580		
T90							5590		
T100							5600		
	5 mm	5485-5		5481-M5					
	6 mm	5485-6		5481-M6	4286				
	7 mm	5485-7		5481-M7					
	8 mm	5485-8		5481-M8					
	9 mm	5485-9							
	10 mm	5485-10		5481-M10					
	11 mm	5485-11							
	12 mm	5485-12		5481-M12				5054-12	
	13 mm	5485-13							
	14 mm	5485-14		5481-M14				5054-14	
	17 mm	5334-H17		5481-M17				5054-17	
	19 mm			5481-M19				5054-19	
21 mm							5054-21		
22 mm							5054-22		
23 mm							5054-23		
24 mm							5054-24		
	M 4	5487-M4		5482-M4					
	M 5	5487-M5		5482-M5					
	M 6	5487-M6		5482-M6					
	M 8	5487-M8		5482-M8	4358				
	M 9			5482-M9					
	M 10	5487-M10		5482-M10	4462				
	M 12	5381-M12		5482-M12		4463			
	M 14	5381-M14		5482-M14					
	M 16	5381-M16		5482-M16				5054-M16	
	M 18	5381-M18		5184-M18				5054-M18	
M 24							5054-M24		
	M 5			5483-M5					
	M 6			5483-M6					
	M 7			5483-M7					
	M 8			5483-M8					
	M 9			5483-M9					
	M 10			5483-M10					
	M 12			5483-M12					
	M 13			5483-M13					
M 14			5483-M14						