

Bit Socket | T-Star for VAG polyDrive cylinder head bolts



12.5mm $\frac{1}{2}$ "

168 mm



T52

9386



Quick-Finder

Impact Bit Sockets

Quick-Finder

Impact Bit Sockets

		42 mm	55 mm	75 mm	100 mm	140 mm	55 mm	
<p>T-Star (for Torx)</p>	T20	5486-T20	5369	5480-T20	5469			
	T25	5486-T25	5370	5480-T25	5470			
	T27	5486-T27	5367		5467			
	T30	5486-T30	5371	5480-T30	5471			
	T40	5486-T40	5372	5480-T40	5472			
	T45	5486-T45	5373	5480-T45	5473			
	T47		5378					
	T50	5486-T50	5374	5480-T50	5474			
	T55	5486-T55	5375	5480-T55	5475			
	T60	5486-T60		5480-T60				
	T70	5486-T70		5480-T70				
	T80	5486-T80		5480-T80				
	<p>Internal hexagon</p>	5 mm	5485-5		5481-M5			
6 mm		5485-6		5481-M6	4286			
7 mm		5485-7		5481-M7				
8 mm		5485-8		5481-M8				
9 mm		5485-9						
10 mm		5485-10		5481-M10				
11 mm		5485-11						
12 mm		5485-12		5481-M12			5054-12	
13 mm		5485-13						
14 mm		5485-14		5481-M14			5054-14	
17 mm				5481-M17			5054-17	
19 mm				5481-M19			5054-19	
<p>Spline (for XZN)</p>	21 mm						5054-21	
	22 mm						5054-22	
	23 mm						5054-23	
	24 mm						5054-24	
	M 4	5487-M4		5482-M4				
	M 5	5487-M5		5482-M5				
	M 6	5487-M6		5482-M6				
	M 8	5487-M8		5482-M8	4358			
	M 9			5482-M9				
M 10	5487-M10		5482-M10	4462				
<p>Ribe (for Ribe)</p>	M 12	5381-M12		5482-M12		4463		
	M 14	5381-M14		5482-M14				
	M 16	5381-M16		5482-M16			5054-M16	
	M 18	5381-M18		5184-M18			5054-M18	
	M 24						5054-M24	
	M 5			5483-M5				
	M 6			5483-M6				
	M 7			5483-M7				
M 8			5483-M8					
M 9			5483-M9					
M 10			5483-M10					
M 12			5483-M12					
M 13			5483-M13					
M 14			5483-M14					